

---

# **Thermal printer guideline for:**

- **Add new paper size**
- **Change new paper size**

**Prepared for printer model:**

- 1) Xprinter XP-420B**
  - 2) Xprinter XP-460B**
  - 3) SoonMark M8**
-

# CONTENT

Instructions:

Clicking at each topic below will bring you to the page directly.


|  |           |
|--|-----------|
| <b>Objective</b>   | <b>3</b>  |
| <b>A) Add new paper size:</b>                              |           |
| i. Paper spindle   | 4         |
| ii. External roll paper holder                             | 6         |
| <b>B) Change new paper size:<br/>(Calibration process)</b> |           |
| i. X-Printer 420B  | 7         |
| ii. X-Printer 460B   | 8         |
| iii. SoonMark M8   | 9         |
| <b>C) Size setting:</b>                                    |           |
| i. 80mmx50mm   | 11        |
| ii. 100mmx150mm  | 19        |
| <b>Printer ready to be use</b>                             | <b>21</b> |

We are preparing this guideline for the user on how to add and change to a new paper size for your current Thermal Printer. What you need to do is:

- i. Placed the new paper roll.
- ii. Do the calibration process before setting the size. Here, we listed the printer that we already tested:
  - X-Printer 420B
  - X-Printer 460B
  - SoonMark M8
- iii. After completed the calibration, do setting the Printer Preferences & Printer Properties to set a new size.


# A) Add new paper size

- i. Insert the paper roll inside the printer:
  - If the roll can fit inside the printer, use the paper spindle.



**Core Adapter** will be placed at both sides to secure the label roll while printing.

The **New** sticker/label should face up.




# How to insert the paper roll?



## Step 1

Open the top cover.



## Step 2

Insert the paper roll.

- Insert the paper using the paper spindle.
- Then, use the clips on both sides to secure the paper.

Paper spindle

Secure clips

The sticker surface should face up

# A) Add new paper size

ii. Insert the paper roll outside the printer:

- If the roll is too big and cannot fit inside the printer, use the external roll paper holder.



**(Sample external roll mount)**

The sticker surface should face up after assembling the roll mount.


Insert the paper through this hole.



## B) Change new paper size

### X-Printer 420B:

Do the calibration process.



#### Step 1

- Plug in the battery and the cable to connect with a PC/Laptop.
- Then, turn on the **Power Switch** button.



#### Step 2

- Press the feed button until the LED light color **change** from **blue** to **red** color.

Now, let's set the paper size for this printer . Click either (a) or (b):

- a) Setting to the 80mm x 50mm
- b) Setting to the 100mm x 150mm

## B) Change new paper size

### X-Printer 460B:

Do the calibration process.



Power  
Switch

Power Jack

USB Interface

### Step 1

- Plug in the battery and the cable to connect with a PC/Laptop.
- Then, turn on the **Power Switch** button.



### Step 2

- Press this feed button and the LED indicator will light up.

Feed Button with  
LED Indicator Light

Now, let's set the paper size for this printer . Click either (a) or (b):

- a) Setting to the 80mm x 50mm
- b) Setting to the 100mm x 150mm



## B) Change new paper size

### SoonMark M8:

Do the calibration process.



USB Printer  
Port

Power Jack  
Adapter Slot

Power  
Switch

### Step 1

- Plug in the battery and the cable to connect with a PC/Laptop.
- Then, turn on the **Power Switch** button.



Feed Button with  
LED Indicator Light

### Step 2

- Press and hold the '**Feed Button**' until it blinks twice with a red light. Then, the calibration is complete.

Now, let's set the paper size for this printer . Click either (a) or (b):

- a) Setting to the 80mm x 50mm
- b) Setting to the 100mm x 150mm

## C) Size setting

After do the calibration process, each printer need to set the printer setting.

There are two (2) sizes:

- i. 80mm x 50mm (Print Destination Sticker)
- ii. 100mm x 150mm (A6 size - AWB)

\*The image provided is only for demonstration purposes. This size setting is applicable to any printer model.


# C) Size setting

## Paper size: 80mmx50mm

The size is for Print Destination sticker.


### Step 1

Go to setting and click on the **Devices**.




### Step 2

Then, go to **Printers & scanners** and find the name of the printer (e.g., Xprinter XP-420B). Click on the printer and select the **Manage** button.




# C) Size setting



## Step 3

Go to **Printing Preferences** to set the paper size for the printer that had been chosen (e.g., Xprinter XP-420B).



## Step 4


In the **Page Setup**, create a new custom size for this printer. The paper size is 80mm x 50mm.

To create a new size, click on the **New** button.

# C) Size setting

## Step 5

Set the label size according to the paper size, which is 80mm x 50mm.



a) Name:

Fill out the printer model's name (e.g., xp-420b)

b) Type:

Choose a **Die-cut Labels**

c) Label Size:

Width is **3.15 in** (80mm)


Height is **1.97 in** (50mm)

Once done, click on the **OK** button.

## C) Size setting

### Step 6

After complete with setting the size, click on the **Apply** button. Then, click **OK**.



(2)


(1)

Now, the printer is ready to be used.

# C) Size setting


## Step 7

Click on the **Printer Properties**.



## Step 8

Open the **Advanced** page. Click on the **Printing Defaults**.




# C) Size setting

## Step 9

Under the **Page Setup**, at the **Name** sections, find out the name that has been set from the previous step.

If you can't find it, click on the **New** button to set a new size.






# C) Size setting

## Step 10

Set the label size according to the paper size, which is 80mm x 50mm.



a) Name:

Fill out the name for easy reference (e.g., PrintDest)

b) Type:

Choose a **Die-cut Labels**

c) Label Size:

Width is **3.15 in** (80mm)


Height is **1.97 in** (50mm)

Once done, click on the **OK** button.

## C) Size setting

### Step 11

After complete with setting the size, click on the **Apply** button. Then, click **OK**.



Now, the printer is ready to be used.


# C) Size setting

## Paper size (A6): 100mm x 150mm

The size is for print the AWB.


### Step 1

Go to setting and click on the **Devices**.




### Step 2

Then, go to **Printers & scanners** and find the name of the printer (e.g., Xprinter XP-420B). Click on the printer and select the **Manage** button.




# C) Size setting



## Step 3

Go to **Printing Preferences** to set the paper size for the printer that had been chosen (e.g., Xprinter XP-420B).



## Step 4

In the **Page Setup**, choose the paper size which is 4 x 6 (4.00in x 6.00in) for A6 size.

After that, click on the **Apply** button. Then, click on the **OK** button.

Now, the printer is ready to be used.

(2)


(1)

# Printer ready to be use

After completing all the steps, your printer is ready, and you can start printing your sticker. Make sure you already followed the below steps:

- i. Placed the new paper roll.
- ii. Do the calibration process before setting the size.
- iii. After completed the calibration, do setting at the Printer Preferences for a new paper size.

You can click on the **‘Print a test page’** button to do testing. Below is the sample image for demonstration purposes only. (*Sample printer Xprinter 420B*)



---

# Thank You

---